




6


Use with the TV / Verwendung mit dem Fernseher
Utiliser avec le téléviseur / Používanie s televízorom



3




4



7

Use with an audio device / Verwendung mit einem
Audiogerät / Utiliser avec un appareil audio / Používanie
s audio zariadením



8

For further information, please refer to the User Guide.

Weitere Informationen zur Anwendung finden Sie in der
Gebrauchsanweisung.

Pour plus d'informations, veuillez vous référer aux instructions
d'utilisation.

Ďalšie informácie nájdete v návode na použitie.



Model: Roger Select 3

Distibútor pre Slovenskú republiku:
Artsonic s. r. o.
so sídlom Radlinského 27,
811 07 Bratislava
www.artsonic.sk
www.phonak.sk

Výrobca:
Sonova Communications AG
Herrenschwandweg 4
CH-3280 Murten
Švajčiarsko

www.phonak.com/roger

sonova
HEAR THE WORLD

PHONAK
life is on

A Sonova brand

Roger Select™

Quick setup guide | Schnellstartanleitung
Guide d'installation rapide | Stručný návod

roger




7 613388 747850

029-3369-46/V1.00/2025-02/haj/SB © 2024 Sonova AG. Všetky práva vyhradené.





1

Charging / Aufladen
Charger / Nabíjanie




2

Switching on / Einschalten
Mettre en marche / Zapínanie




3

Connecting / Verbinden
Connecter / Pripojovanie




10 cm





4

Use on the table / Verwendung auf dem Tisch
Utilisation sur la table / Používanie pri stole



5

Use with a speaker / Verwendung mit einem Sprecher
Utilisation avec un locuteur / Používanie s moderátorom



or / oder / ou / alebo

